

THIS IS A CONTROLLED DOCUMENT.

1281 (7/63)

APPLICATOR PARTS LIST

TYPE **LENGTHWISE BRUSH CONTACT AMPLIVAR**

MAGNET PICKUP WIRE STOP
AMP INCORPORATED HARRISBURG, PENNA.
RIGHT HAND

| NO. | DESCRIPTION | REQ. | PART NO. | NO. | DESCRIPTION | REQ. | PART NO. | CRIMPING DATA | | | TERMINALS | |
|-----|-------------------------|------|----------|------|----------------------|------|----------|-----------------------------|----------------------------------|--------------|------------------------|---------|
| | | | | | | | | CMA | CRIMP | HT. | | |
| 1 | WIRE CRIMPER | 1 | 4539173 | 42 | | | | 700 | .057 | | 62214-2 | |
| 2 | INS. CRIMPER | | | 43 | | | | 800 | .058 | | | |
| 3 | ANVIL | 1 | 14734050 | 44 | HOLD DOWN (100 HIGH) | 1 | 375826 | 1000 | .060 | | | |
| 4 | ANVIL SPACER | | | 45 | | | | 1200 | .061 | | | |
| 5 | SHEAR BLADE | 1 | 4570862 | 46 | | | | 1400 | .063 | | | |
| 6 | REAR SHEAR PLATE | 1 | 3850134 | 47 | | | | 1600 | .063 | | | |
| 7 | SHEAR BLADE SPACER | 2 | 370954 | 48 | | | | 1800 | .064 | | | |
| 8 | FRONT SHEAR PLATE | 1 | 372064 | 49 | | | | 2000 | .066 | | | |
| 9 | REAR ANVIL SPACER PLT. | | | 50 | | | | CRIMP | SIZE | TYPE | | FEED |
| 10 | FRONT ANVIL SPACER PLT. | | | 51 | | | | WIRE | .090 | F | | |
| 11 | TOOL SPACER | 1 | 370439 | 52 | | | | INSUL. | | | | .500 |
| 12 | CRIMP SPACER | | | 53 | HOLD DOWN (BLADE MT) | 1 | 18112271 | SLEEVED | | | | |
| 13 | FRONT STRIP GUIDE | 1 | 3790341 | 54 | | | | INSULATION RANGE | WIRE RANGE | | | |
| 14 | REAR STRIP GUIDE | 1 | 371638 | 55 | | | | | | 700-2000 | | |
| | | | | 56 | FLOATING WIRE STOP | 1 | 5650812 | EXPLODED VIEW | | | | |
| 15 | RAM | 1 | 471911 | 57 | BUSHING | REF | 811258-2 | A-6000 A-6000-1 | | | | |
| 16 | TOOL HOLDER | | | 58 | STOP | REF | 811259-2 | REMARKS: Δ INDICATES | | | | |
| 17 | ADJ. CRIMP MOUNT | | | 59 | SPACER | REF | 811260-1 | PARTS USED ON | | | | |
| 18 | ADJ. BLOCK | | | 60 | SLIDE | REF | 811280-1 | 565081-2 ASSY. (ITEM 56) | | | | |
| 19 | APPLICATOR MOUNT | 1 | 570656 | 61 | MOUNT | REF | 811282-1 | RIGHT HAND | | | | |
| 20 | BASE PLATE | | | 62 | | | | | | | | |
| 21 | BASE BLOCK | | | 63 | HOLDER-MAGNET | REF | 811284-1 | | | | | |
| 22 | STRIP GUIDE PLATE | | | 64 | BRACKET | REF | 811285-1 | | | | | |
| 23 | ANVIL HOLDER | 1 | 370526 | 65 | | | | | | | | |
| 24 | AUX. ANVIL HOLDER | 1 | 377515 | | MISCELLANEOUS | | | | | | | |
| 25 | STRIPPER | | | 66 | MAGNET | REF | 811287-1 | | | | | |
| 26 | STRIPPER MOUNT | REF | 8113231 | 67 | WIRE STOP | REF | 4653442 | | | | | |
| 27 | RETAINER PLATE | REF | 372251 | 68 | | | | | | | | |
| 28 | STRIPPER MOUNT BRACKET | | | 69 | | | | | | | | |
| 29 | STRIPPER BUSHING | | | 70 | | | | | | | | |
| 30 | STOCK DRAG | 1 | 375381 | 71 | TENSION ADJ. PLATE | 1 | 374999 | | | | | |
| 31 | STOCK DRAG HANDLE | | | 72 | | | | | | | | |
| 32 | STOCK DRAG STUD | 2 | 354045-1 | REV. | REVISION RECORD | DATE | BY | ECN | THIS APPLICATOR IS TO BE USED ON | | | |
| 33 | STOCK DRAG SPRING | 2 | 1238471 | A | ECN A-395892 | 9-92 | MO/TE | - | AMP-O-LECTRIC 1-471273-3 | | | DIST. 4 |
| 34 | STOCK DRAG ADJ. SCREW | 2 | 372997 | A1 | ECN 0150-0249-03 | 3-03 | MY/TE | | ALIGN. GA. 679597-1 | | | |
| 35 | FEED FINGER HOLDER | | | | | | | | SERIAL NO. | DATE SHIPPED | DESIGNED | |
| 36 | FEED FINGER | 1 | 375093 | | | | | | | | R. Bennett 12-26-74 | |
| 37 | FEED FINGER TIP | | | | | | | | CUSTOMER NAME AND ADDRESS | | CHK'D. 1/2/75 | |
| 38 | FEED FINGER SPACER | | | | | | | | | | APP'D. | |
| 39 | BASE CASTING | 1 | 570238 | | | | | | | | | |
| 40 | GUARD ASSY. | 1 | 4576642 | | | | | | APPLICATOR NUMBER | REV. A1 | 5661492 | |
| 41 | | | | | | | | | | | SHEET 1 OF 1 | |

RELEASED FOR REPRODUCTION BY AMP INCORPORATED. ALL RIGHTS RESERVED. THE DRAWING IS UNPUBLISHED. COPYRIGHT 2000